

N4A three phase start-up guide

Please read through the following information prior to using your N4A.

Electrical Specification

• Input Voltage		
• N4A18	• 400V AC +/-10% 3PH	
• N4A30		
• N4A67		
• Input Frequency		
• N4A18	• 45 - 65 Hz	
• N4A30		
• N4A67		
• Input Current - per phase		
• N4A18	• 60A continuous or 120A inrush	
• N4A30	• 80A continuous or 160A inrush	
• N4A67	• 160A continuous or 220A inrush	