



N4A67 Connection Details

This section identifies the terminals that can be found on the rear of the N4A67

Rear Connection Terminal Blocks associated with the N4A67



Input connections:




3 phase input and earth
L1, L2, L3, Earth (No Neutral)

Output connections:

Sense Terminals

REGEN bus connector
(optional)



Three phase and Neutral sense terminals
L1, L2, L3, Neutral

N4A67 Connection Diagram

